

ROTAMIR S.p.A.

MANUALE DI USO E MANUTENZIONE - RICAMBI
MANUEL D'ENTRETIEN - PIECES DE RECHANGE
OPERATING MAINTENANCE - PARTS MANUAL
BEDIENUNG UND WARTUNGSANLEITUNGEN
MANUAL DE USO Y MANTENIMIENTO - RECAMBIOS

MARTELLO - MARTEAU - HAMMER - MARTILLO

OLS 95

ecosilent

DETAILS LIST OLS 95 ECOSILENT TAB. A

POSITION	DESCRIPTION	CODE	QUANTITY
1	ACCUMULATOR CHARGE VALVE CAP	Con part 12	1
2	T.C.E.I. SCREW M10x50	133-187-S	15
3	ACCUMULATOR CAP	259-004-S	1
4	ACCUMULATOR MEMBRANE	210-003-S	1
5	ACCUMULATOR BODY	053-065-S	1
6	T.C.E.I. SCREW M8x25	133-133-S	15
7	OR 6412 SEAL	023-070-S	1
8	BELLEVILLE WASHER	043-069-S	1
9	SLIDE VALVE GUIDE BUSHING	223-115-S	1
10	SLIDE VALVE	033-024-S	1
11	ACCUMULATOR CHARGE SEAL CAP	Con part 12	1
12	COMPLETE ACCUMULATOR CHARGE VALVE	024-024.5-F	1
13	VALVE SEAL	Con part 12	1
14	VALVE BODY	053-067-S	1
15	HEAD BODY	053-066-S	1
16	HEXAGONAL NUT M14x1,5	135-075-S	1
17	MACHINED SCREW BACK PRESSURE REGULATION	092-051-S	1
18	1/2" BONDED WASHER	015-201-S	2
19	EXTENSION 3/8"M 1/2"M L=26mm	189-1032-S	1
20	OR 106 VITON SEAL	023-121-S	1
21	EXTENSION 1/2"M 1/2"M L=26mm	189-1025-S	1
24	BEATING PISTON	048-028-S	1
27	CYLINDRICAL PIN 10x40	143-202-S	1
28	POLYPAC I/GR SEAL	023-072-S	1
29	OR CC16-4350 SEAL	023-320-S	1
30	CYLINDER	002-031-S	1
31	TIE ROD	112-013-S	4
32	SCRAPER STAND SPACER	009-119-S	1
34	FORE-CYLINDER	264-030-S	1
35	LUBRICATOR M8	265-008-S	1
36	ELASTIC PIN 8x30	143-300-S	1
37	TOOL-HOLDER PIN	018-014-S	1
38	S.T.E.I. SCREW 1/8" (PIN)	218-001-S	5
39	ELASTIC PIN 10x30	143-320-S	1
40	EHRCO SEAL	023-069-S	1
42	CAP NUT M18x1,5	138-002-S	4
43	PAWL SPRING	043-039-S	1
44	PAWL PIN	018-015-S	1
45	TOOL GUIDE BUSHING	223-098-S	1

POSITION	DESCRIPTION	CODE	QUANTITY
47	STRAIGHT CHISEL TOOL	176-453.1-S	/
48	CONIC TOOL	176-450.1-S	/
49	90° CHISEL TOOL	176-452.1-S	/
50	SEAL KIT	204-206-S	1

DETAILS LIST OF OLS 95 ECOSILENT – TAB. B

POSITION	DESCRIPTION	CODE	QUANTITY
51	INTERMEDIATE PLASTIC THICKNESS	177-331-S	1
52	LOWER PLASTIC THICKNESS	177-330-S	1
53	FRAME ASSEMBLY	024-9665-S	1
54	UPPER PLASTIC THICKNESS	177-334-S	1
55	PLASTIC THICKNESS FOR ACCUMULATOR CAP	177-333-S	1
56	PLASTIC THICKNESS FOR HEAD	177-332-S	1
57	SPLIT PINS Diam. 6	104-202-S	1
58	PIN	*	2
59	BUSHES	*	4
60	CRADLE ASSEMBLY	024-943-S	1
61	CE LABEL	238-139-S	1
62	MANOMETER PIPE	089-175-S	1
63	MANOMETER	206-050-S	1
64	M12 SELF-LOCKING NUT	137-060-S	10
65	FLAT WASHER DIAM. 13x24x2,5	015-034-S	20
66	TE SCREW M12x45	132-195-S	10
67	T.E. SCREW M6x16	132-062-S	4
68	FLAT WASHER DIAM. 6,6x12x1,5	015-027-S	4
69	CLOSURE PLATE SADDLE	208-256-S	1
70	CLOSURE PLATE SLOTTED HOLE BACK PRESSURE	208-260-S	1
71	T.C.E.I. SCREW M8x10	133-130-S	2
72	NAKED HAMMER	122-2475-F	1

NOTE:

For any orders of details marked with an asterisk, always indicate the type of support machine with which you intend to couple the hammer, or important measurements such as the support machine pivot diameters and arm thickness.

